
DPA+ Dual | DPA+ LCD Dual RS485 BACnet

Differential Pressure Transmitter



Datasheet

Subject to technical alteration Issue date: 21.09.2018 • A002





The following illustrations show the version with LCD

Application

Differential pressure and volume flow transducer for monitoring differential pressure and volume flow of air and other non-flammable and non-aggressive gases. LCD models with RGB background light have a transparent cover. Display configuration, k-values for flow calculation (default 1500) and threshold values for color changes can be parameterized via Thermokon USEapp. The mounting base (included in delivery) allows mounting on a level surface or mounting on DIN rail TS35 (35x7,5 mm) according to EN 60715.

Types Available

Differential pressure and volume flow transducer optional with display - RS485 BACnet MS/TP

DPA2500+ (LCD) RS485 BACnet MultiRange <AZ>

MultiRange: Measuring ranges adjustable at the transducer <AZ>: automatic zero-point calibration (optional)

Security Advice - Caution



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

Page 2 / 5 Issue date: 21.09.2018

Notes on Disposal



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

Technical Data

Measuring values	differential pressure, volume flow		
Medium	air or other non-flammable/non-aggressive gases		
Output voltage	$010~V~or~05~V,$ min. load $10~k\Omega,$ (live-zero Konfiguration über Thermokon USEapp)		
Network technology	RS485 BACnet MS/TP		
Power supply	1535 V = or 1929 V ~		
Power consumption	max. 2,3 W (24 V =) max. 4,3 VA (24 V ~)		
Measuring range velocity	0 750.000 m³/h (default), parametrierbar über Thermokon USEapp		
Measuring range pressure *selectable at the device	-100+100 0+100 0+250 0+500 0+1000 0+1500 0+2500 0+2500 Pa		
*deviation from calibration reference device (calibrator)	±5 Pa bei Messbereich <500 Pa, ±10 Pa bei Messbereich >500 Pa,		
Max. working overpressure	40 kPa		
Calibration	manually, automatic zero-point calibration (optional)		
Sensor	piezo measuring element		
Display (optional)	LCD 29x35 mm with RGB backlight units, pressure: Pa, inchWC, volume flow: m3/h, cfm (configurable)		
Enclosure (type-dependent)	without LCD enclosure USE-L, PC, pure white, with removable cable entry	with LCD enclosure USE-L, PC, pure white, cover PC, transparent, with removable cable entry	
Protection	IP65 according to EN 60529		
Cable entry	M25, for wire max. Ø=7 mm, seal insert for fourfold cable entry		
Connection electrical	Mainboard removable plug-in terminal, max. 2,5 mm²	Plug-in card removable plug-in terminal, max. 1,5 mm²	
Connection mechanical	pressure connection male Ø=5,0 mm / Ø=6,3 mm, connection tube: PVC, soft		
Ambient condition	-10+50 °C, max. 85% rH short term condensation		
Mounting	screw mounted onto flat surface, prepared for mounting on DIN rail TS35 (35x7,5 mm) according to EN 60715		



Declaration of conformity

The declaration of conformity of the products can be found on our website https://www.thermokon.de/.

Configuration



App Store

The Thermokon bluetooth dongle with micro-USB is required for communication between USEapp and USE-M / USE L (Item No..: 668262). Commercial bluetooth dongles are not compatible.

Application-specific reconfiguration of the devices can be carried out using the Thermokon USEapp. The configuration is carried out in the voltage-supplied state.


The configuration-app and the app description can be found in the Google Play Store or in the Apple App Store.

Issue date: 21.09.2018 Page 3 / 5

Connection Plan

RS485 cable is looped through, connect both cable shields using the enclosed 2-pol. Connect terminal as shown.


DPA+ (LCD) Dual RS485 BACnet Multirange






(differential pressure 2 | 0..10 V) (differential pressure 1 | 0..10 V) (15..35 V = or 19..29 V ~)






Dip switch, pressure sensor (2x)




S1 - Dip-Schalter Block 1, Drucksensor 1

S2 - Dip-Schalter Block 2, Drucksensor 2

Measuring range adjustment



default



The BACnet address of the device is set binary coded in the range of 1 ... 127 via 7 dip-switches. (the address 0 is reserved and cannot be selected).



BACnet Objects:

USE-RS485 BACnet interface


A detailed description of the BACnet interface can be found at the following link:

→ **Download**

Page 4 / 5 Issue date: 21.09.2018

Dip switches, plug-in card

Address block 1



Flow calculation: (default parameters)

 $q = k * \sqrt{2 * \frac{\Delta p}{a}}$ with k=1500, fan manufacturer Rosenberg, Comefri, Nicotra Gebhardt, default measuring range 0..750.000 m³/h.

Further calculation formulas, fan manufacturers and k-values can be selected via the USEapp.


Automatic zero-point correction - (optional)



Transmitters equipped with the auto-zero correction are maintenance free.

The auto-zero correction electronically adjusts the transmitter zero every 10 minutes. The function eliminates all output signal drift due to thermal, electronic or mechanical effects. The auto-zero correction takes approx. 4 seconds after which the device returns to its normal measuring mode. During the 4 second correction period, the output and display values will freeze to the latest measured value.

Manual zero-point correction (for devices without auto-zero function)



In normal operation zero point correction should be executed every 12 months.

Attention! For executing zero point correction the power supply must be connected one hour before.

- Release both connection tubes from the pressure terminals + and -
- · Press the button until the LED lights permanently
- Wait until the LED flashes again and reinstall the connection tubes to the pressure ports (note + and -)

Measuring values


Objects	Access	Description		Unit
AI-8	R	differential pressure 1	SI	Pa
AI-9	AI-9 R	lumetric flow 1 (If Present Value is set to 2 in the AV-41 object, the value	SI	m³/h
		scales in the unit m³/s)		m³/s
Ai-10	R	differential pressure 2	SI	Pa
Ai-11 R	D	volumetric flow 2 (If Present Value is set to 2 in the AV-41 object, the value scales in the unit m³/s)	Si	m³/h
	N			m³/s

Issue date: 21.09.2018 Page 5 / 5


Mounting Advices

Before installing the device, please check the leak tightness of the pressure lines. A prerequisite for the operation is a proper installation of all electrical supply, control and sensing leads as well as the pressurized connection line.

- In order to connect the device, the process lines must be unpressurized
- Consider the suitability of the device for the medium to be measured
- Consider maximum pressures



Dimensions (mm)



Accessories (included in delivery)

Mounting base enclosure USE-L ltem No. 668361 ltem No. 484268 KKS40 kit ltem No. 430135

Item No. 698511

• 2 plastic duct flanges • 4 mounting screws 4x20

Mounting kit universal

• Cover screw + screw cover• 2 Rawlplugs • 2 Screws (countersunk head) • 2 Screws (rounded head)

.

Accessories (optional)