# FTA54+ Relay

Outdoor sensor for relative humidity and temperature



#### **Datasheet**

Subject to technical alteration Issue date: 26.06.2017





# **Application**

Sensor for measuring humidity and temperature in outdoor areas. In delivery condition, the sensor is designed for measuring temperature and relative humidity. Alternatively the output can be set to absolute humidity, enthalpy or dew point (depending on the model, changeable via jumper or using Thermokon USEapp). With the option board relay two-point controllers or a 2-stage 2-point controller for temperature or humidity can be realized. A mounting base for mounting on a level surface and fixing material are included in delivery.

### Types Available

Outdoor humidity sensor temperature + humidity - active 2x 0..10 V | Relay

FTA54+ VV Relay

Options: Additional passive temperature sensor

eg: PT100/PT1000/NI1000/NI1000TK5000/NTC10K... and other sensors on request

# Security Advice – Caution



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

Page 2 / 4 Issue Date: 26.06.2017

# **Notes on Disposal**



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

# **Build-up of Self-Heating by Electrical Dissipative Power**

Temperature sensors with electronic components always have a dissipative power, which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. This dissipative power has to be considered when measuring temperature. In case of a fixed operating voltage ( $\pm$ 0,2 V) this is normally done by adding or reducing a constant offset value. As Thermokon transducers work with a variable operating voltage, only one operating voltage can be taken into consideration, for reasons of production engineering. Transducers 0..10 V / 4..20 mA have a standard setting at an operating voltage of 24 V =. That means, that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics. If a re-calibration should become necessary later directly on the sensor, this can be done by means of a trimming potentiometer on the sensor board.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

### Application Notice for Humidity Sensors

Refrain from touching the sensitive humidity sensor/element. Touching the sensitive surface will void warranty.

For standard environmental conditions re-calibration is recommended once a year to maintain the specified accuracy.

When exposed to high ambient temperature and/or high levels of humidity or presence of aggressive gases (i.e. chlorine, ozone, ammonia) the sensor element may be affected and re-calibration may be required sooner than specified. Re-calibration and deterioration of the humidity sensor due to environmental conditions are not subject of the general warranty.


#### Technical Data

Measuring values	temperature, humidity (humidity output configurable)	
Output voltage	2x 010 V, min. load 10 kΩ (live-zero configuration via Thermokon USEapp)	
Output switching contact	2 floating contacts for 24 V ~ or 24 V = / 3 A	
Power supply	1535 V = or 1929 V ~	
Power consumption	max. 2,3 W (24 V =)   4,3 VA (24 V ~)	
Measuring range temp	-20+80 °C (default setting), optionally configured via Thermokon USEapp	
Measuring range humidity	0100% rH non-condensing, optionally configured via Thermokon USEapp (enthalpy, absolute humidity, dew point)	
Accuracy temperature	±0,3 K (typ. at 21 °C)	
Accuracy humidity	±2% between 1090% rH (typ. at 21 °C)	
Enclosure	enclosure USE-M, PC, pure white, with removable cable entry	
Protection	IP65 according to EN 60529	
Cable entry	M20 for cable max. Ø=10 mm, seal insert for double cable entry for wire max Ø=6 mm	
Connection electrical	removable plug-in terminal, max. 2,5 mm <sup>2</sup>	
Filter	stainless steel wire mesh	
Ambient condition	-20+70 °C, max. 85% rH short term condensation	
Notes	additional passive sensor available (type VVS   AAS)	

Issue Date: 26.06.2017 Page 3 / 4


# **Mounting Advices**

In case of outdoor installation avoid direct rain and sun contact. Probably use sun respectively rain protection. Cable entry from bottom or side. For side cable routing set loop so that precipitation can drain defined. Observe permissible ambient condition.



# **Connection Plan**

### FTA54+ LCD VV Relay



# **Application Notice**

After a certain time, dirt in the air can collect on the filter and then adversely affect the operation of the sensor. Under normal ambient condition an annual maintenance is recommended. Rinse the filter after cleaning with distilled water and dry it using clean oil-free air or nitrogen. Extremely contaminated filters should be replaced. At extreme ambient conditions, e.g. corrosive gases, the humidity sensor may have to be changed.

Page 4 / 4 Issue Date: 26.06.2017

### Configuration



The Thermokon bluetooth dongle with micro-USB is required for communication between USEapp and USE-M / USE L (Item No..: 668262). Commercial bluetooth dongles are not compatible.


Application-specific reconfiguration of the devices can be carried out using the Thermokon USEapp. The configuration is carried out in the voltage-supplied state.



The configuration-app and the app description can be found in the download area of our webpage.

→ **Download (APK-file for Android)** 

# Dimensions (mm)



# Accessories (included in delivery)

Rain protection Mounting base

Mounting kit 5 (only version VV & AA)

• Cable entry M16 • Cover screw • 2 Rawlplugs • 2 Screws (countersunk head)

Mounting kit 6 (only version Relay)

• Cable entry M20 • seal insert for double cable entry 2x 6 mm • Cover screw • 2 Rawlplugs • 2 Screws (countersunk head)

Item No. 670715 Item No. 631228 Item No. 640558

Item No. 674157

# **Accessories (optional)**

Bluetooth dongle
Cable entry M25 USE white, sealing insert 4x Ø=7 mm (4 pcs)

Filter stainless steel, wire mesh

Item No. 668262 Item No. 641364 Item No. 231169

#### M16 Sealing inserts cable entry (packaging unit 10 pcs.)

Ø	3 mm	5 mm	7 mm	8 mm
Item No	641036	641012	639248	641340

#### M20 Sealing inserts cable entry (packaging unit 10 pcs.)

Ø	2x6 mm	2x7 mm	6 mm	8 mm
Item No	641319	641333	641074	641081