Duct sensor for humidity and temperature

Datasheet

Subject to technical alteration Issue date: 19.07.2017



thermoko



Application

Duct sensor for measuring humidity and temperature in gaseous media of heating, ventilation and air-conditioning systems. In delivery condition, the sensor is designed for measuring temperature and relative humidity. Alternatively the output can be set to absolute humidity, enthalpy or dew point (changeable using Thermokon USEapp). With the option board relay two-point controllers or a 2-stage 2-point controller for temperature or humidity can be realized. A mounting base for mounting on a level surface and fixing material are included in delivery.

Types Available

Duct humidity sensor with display temperature + humidity - active RS485 Modbus

FTK+ 140 VV Relay incl. MF20 FTK+ 270 VV Relay incl. MF20 FTK+ 400 VV Relay incl. MF20

Security Advice – Caution



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

Notes on Disposal



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

Build-up of Self-Heating by Electrical Dissipative Power

Temperature sensors with electronic components always have a dissipative power, which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. This dissipative power has to be considered when measuring temperature. In case of a fixed operating voltage (\pm 0,2 V) this is normally done by adding or reducing a constant offset value. As Thermokon transducers work with a variable operating voltage, only one operating voltage can be taken into consideration, for reasons of production engineering. Transducers 0..10 V / 4..20 mA have a standard setting at an operating voltage of 24 V =. That means, that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics. If a re-calibration should become necessary later directly on the sensor, this can be done by means of a trimming potentiometer on the sensor board.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

Application Notice for Humidity Sensors

Refrain from touching the sensitive humidity sensor/element. Touching the sensitive surface will void warranty.

For standard environmental conditions re-calibration is recommended once a year to maintain the specified accuracy.


When exposed to high ambient temperature and/or high levels of humidity or presence of aggressive gases (i.e. chlorine, ozone, ammonia) the sensor element may be affected and re-calibration may be required sooner than specified. Re-calibration and deterioration of the humidity sensor due to environmental conditions are not subject of the general warranty.

Technical Data


Measuring values	temperature, humidity (humidity output configurable)		
Output voltage	$2x 010 V$, min. load $10 k\Omega$ (live-zero configuration via Thermokon USEapp)		
Output switching contact	2 floating contacts for 24 V ~ or 24 V = $/ 3 A$		
Power supply	1535 V = or 1929 V ~		
Power consumption	max. 2,3 W (24 V =) 4,3 VA (24 V ~)		
Measuring range temp	-20+80 °C (default setting), optionally configured via Thermokon USEapp		
Measuring range humidity	0100% rH non-condensing, optionally configured via Thermokon USEapp (enthalpy, absolute humidity, dew point)		
Accuracy temperature	±0,3 K (typ. at 21 °C)		
Accuracy humidity	±2% between 1090% rH (typ. at 21 °C)		
Air speed	max. 40 ft./s		
Enclosure	enclosure USE-M, PC, pure white, with removable cable entry		
Protection	IP65 according to EN 60529		
Cable entry	M20 for cable max. \emptyset =10 mm, seal insert for double cable entry for wire max \emptyset =6 mm		
Connection electrical	removable plug-in terminal, max. 2,5 mm ²		
Pipe	PA6, black, Ø=19,5 mm, length=140 270 400 mm		
Filter	stainless steel wire mesh		
Ambient condition	-20+70 °C, max. 85% rH short term condensation		
Notes	additional passive sensor available (type VVS AAS)		

Mounting Advices

The sensor can be mounted on the ventilation duct by means of the mounting flange MF20 TPO (optional with mounting base).




Optional mounting with mounting base (Item No. 631228), please note the installation depth of the sensor pipe.



Connection Plan

FTK+ VV Relay



Application Notice

After a certain time, dirt in the air can collect on the filter and then adversely affect the operation of the sensor. Under normal ambient condition an annual maintenance is recommended. Rinse the filter after cleaning with distilled water and dry it using clean oil-free air or nitrogen. Extremely contaminated filters should be replaced. At extreme ambient conditions, e.g. corrosive gases, the humidity sensor may have to be changed.

668262

631228

641364

231169

Configuration



The Thermokon bluetooth dongle with micro-USB is required for communication between USEapp and USE-M / USE L (Item No ..: 668262). Commercial bluetooth dongles are not compatible.


Application-specific reconfiguration of the devices can be carried out using the Thermokon USEapp. The configuration is carried out in the voltage-supplied state.



The configuration-app and the app description can be found in the download area of our webpage.

→ Download (APK-file for Android)

Dimensions (mm)



Accessories (included in delivery)

Item No. 612562
Item No. 674133

Accessories (optional)	
Bluetooth dongle	Item No. (
Mounting base	Item No. 6
Cable entry M25 USE white, sealing insert $4x Ø = 7 \text{ mm} (4 \text{ pcs})$	Item No. 6
Filter stainless steel, wire mesh	Item No. 2
M20 Sealing inserts cable entry (packaging unit 10 pcs.)	

Ø	2x6 mm	2x7 mm	6 mm	8 mm
Item No	641319	641333	641074	641081
nem no	0-1010	041355	041074	041001

Thermokon Sensortechnik GmbH, Platanenweg 1, 35756 Mittenaar, Germany - tel: +49 2778 6960-0 fax: -400 www.thermokon.com email@thermokon.com FTK+_Relay_Datasheet_en.docx © 2017