LK+ VOC LCD

Duct sensor for air quality, temperature and humidity (optional)



Datasheet

Subject to technical alteration Issue date: 29.05.2017





Application

Duct air quality sensor for detection of VOC air quality, and optional humidity combined in one unit. Designed for duct mounted applications with up to 3 0..10 V outputs. The sensor consists of a transmitter with VOC sensor, based on a heated tin oxide semiconductor. LCD models with RGB background light have a transparent cover. Display configuration and threshold values for color changes can be parameterized via Thermokon USEapp. With the option board relay two-point controllers or a 2-stage 2-point controller for temperature or humidity can be realized.

Types Available

Duct sensor with display VOC + temp + rH (opt.) - active 2x/3x 0..10 V | 2x 4..20 mA

LK+ VOC LCD VV LK+ VOC LCD AA LK+ VOC LCD 3xV

Duct sensor with display VOC + temp - active 2x 0..10 V + relay

LK+ VOC LCD VV Relay

Options: additional passive temperature sensor eg: PT100/PT1000/NI1000/NI1000TK5000/NTC10K... and other sensors on request.

Security Advice – Caution



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Page 2 / 6 Issue date: 29.05.2017

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

Notes on Disposal



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

Build-up of Self-Heating by Electrical Dissipative Power

Temperature sensors with electronic components always have a dissipative power, which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. This dissipative power has to be considered when measuring temperature. In case of a fixed operating voltage (± 0.2 V) this is normally done by adding or reducing a constant offset value. As Thermokon transducers work with a variable operating voltage, only one operating voltage can be taken into consideration, for reasons of production engineering. Transducers 0..10 V / 4..20 mA have a standard setting at an operating voltage of 24 V =. That means, that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics. If a re-calibration should become necessary later directly on the sensor, this can be done by means of a trimming potentiometer on the sensor board.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.


Technical Data

Measuring values		VOC, temperature + humidity (depending on the device)	
Output voltage		13x 010 V or 05 V, min. load 10 kΩ	
		(live-zero configuration via Thermokon USEapp)	
Output Amp	AA	$2x$ 420 mA, max. load 500Ω	
Output switch contact	Relay	2 floating contacts for 24 V ~ or 24 V = / 3 A	
Power supply		1535 V = or 1929 V ~,	
AA		1535 V =	
Power consumption		max. 2,5 W (24 V =) max. 4,3 VA (24 V ~)	
Measuring range temp.		0+50 °C (default setting), optionally configured via Thermokon USEapp	
Measuring range humidity 3xV		0100% rH non-condensing, optionally configured via Thermokon USEapp	
		(enthalpy, absolute humidity, dew point)	
Accuracy temperature VV AA 3xV		±0,5 K (typ. at 21 °C)	
	passive	typ. ±0,3 K (typ. at 21 °C), depending on used sensor	
Accuracy humidity	3xV	±2% between 1090% rH (typ. at 21 °C)	
Air speed		min. 0,3 m/s, max. 12 m/s	
Calibration		self-calibration	
Sensor		VOC sensor (heated metal oxide semiconductor)	
Display		LCD 29x35 mm with RGB backlight	
Enclosure		enclosure USE-M, PC, pure white, cover PC, transparent, with removable cable	
		entry	
Protection		IP65 according to EN 60529	
Cable entry	VV AA	M16, for wire max. Ø=8 mm	
	Relay 3xV	M20, for wire max. Ø=10 mm, seal insert for double cable entry for wire max	
		Ø=6 mm	
Connection electrical		removeable plug-in terminal, max. 2,5 mm ²	
Pipe		PA6, black, Ø=19,5 mm, length 180 mm	
Ambient condition		0+50 °C, max. 85% rH short term condensation	
Mounting		installation is also possible using mounting base	


Issue date: 29.05.2017 Page 3 / 6

Mounting Advices

The sensor can be mounted on the ventilation duct by means of the mounting flange MF20 TPO (optional with mounting base). Align the openings on the sensor tube according to the flow direction.



optional:




Page 4 / 6 Issue date: 29.05.2017


Connection Plan


To change the output voltage range (default 0..10 V to 0..5 V) via jumper, the display must be removed from the board first.


LK+ VOC LCD VV




LK+ VOC LCD AA










LK+ VOC 3xV








LK+ VOC Relay





Issue date: 29.05.2017 Page 5 / 6

Configuration



The Thermokon bluetooth dongle with micro-USB is required for communication between USEapp and USE-M / USE L (Item No..: 668262). Commercial bluetooth dongles are not compatible.

Application-specific reconfiguration of the devices can be carried out using the Thermokon USEapp. The configuration is carried out in the voltage-supplied state.




The configuration-app and the app description can be found in the download area of our webpage.


→ Download (APK-file for Android)

Dismounting Advices

Remove the lower section of the sensor carefully and pulling straight out. Pay close attention to the correct dismantling of the component!



Dimensions (mm)



Page 6 / 6 Issue date: 29.05.2017

Accessories (included in delivery)

Mounting flange MF20
Mounting kit 2 (only version VV & AA)

Item No. 612562 Item No. 640503

- Cable entry M16
- Cover screw
- 2 Screws (rounded head)

Mounting kit 3 (only version 3xV/Relay)

- Cable entry M20
- seal insert for double cable entry 2x 6 mm
- Cover screw
- 2 Screws (rounded head)

Item No. 674133

Accessories (optional)

Bluetooth dongle
Cable entry M25 USE white, sealing insert 4x Ø=7 mm (4 pcs)
Item No. 641364
Mounting base
Filter stainless steel, wire mesh
Item No. 231169

M16 Sealing inserts cable entry (packaging unit 10 pcs.)

for wire with Ø	3 mm	5 mm	7 mm	8 mm
Item No	641036	641012	639248	641340

M20 Sealing inserts cable entry (packaging unit 10 pcs.)

for wire with Ø	2x6 mm	2x7 mm	6 mm	8 mm
Item No	641319	641333	641074	641081